

BODY CONTROL MODULE (BCM) cont.

Fuse	Amps	Circuits protected
F1	-	Not used
F2	10	Inverter Power windows Door locks
F3	7.5	Wireless Accessory Charging Module
F4	-	Not used
F5	-	Not used
F6	10	Anti-theft horn
F7	-	Not used
F8	5	Roof Opening Control Motor Assemblies
F9	5	Intrusion sensor
F10	-	Not used
F11	-	Not used
F12	7.5	Gateway Module Heating, Ventilation and Air Conditioning (HVAC) control module Gear shift module
F13	7.5	Steering Column Control Module (SCCM) Instrument Panel Cluster (IPC)
F14	15	Not used
F15	15	SYNC module Data Link Connector (DLC)
F16	-	Not used
F17	7.5	Headlamp Control Module (HCM) Reductant Dosage Control (RDC) module Trailer brake control